
Garden Party

DESIGNED IN 2021

ASSEMBLY NOTES | REV 03





NEED A HAND?

Contact us at **service@bludot.com** or **844.425.8368** for assistance.

@BLUDOT

We design all our pieces in our Minneapolis studio. Follow along on Instagram for some sneak peeks into the process.

Contents

PAGE Garden Party Garment Rack 3 Parts & Hardware 4 5 Step 01 ATTACH THE BASE TO THE GARMENT RACK UPRIGHTS. Step 02 ATTACH THE WOOD HOOKS. 6 Step 03 ATTACH THE TOP AND HANGING TUBE. 7 Step 04 ATTACH THE SHELF. 8 Step 05 Level the Garment Rack. 9 Garden Party Shelving 10 Parts & Hardware 11 12 Step 01 ATTACH NARROW BASE TO SHELF UPRIGHTS. Step 02 ATTACH THE UPPER BAR AND SHELF. 13 Step 03 ATTACH THE REMAINING SHELVES. 14 15 Step 04 ATTACH THE WOOD HOOKS. Step 05 LEVEL THE BASE. 16 Garden Party Wardrobe System 17 Parts & Hardware 18 19 Step 01 ATTACH NARROW BASE TO SHELF UPRIGHTS. 20 Step 02 ATTACH THE UPPER BAR AND SHELF. 21 Step 03 ATTACH THE REMAINING SHELVES. 22 Step 04 ATTACH THE WIDE BASE TO THE GARMENT RACK UPRIGHTS. 23 Step 05 GANG UNITS TOGETHER. 24 Step 06 ATTACH THE WOOD HOOKS. 25 Step 07 ATTACH THE TOP AND HANGING TUBE. 26 Step 08 ATTACH THE WIDE SHELF. Step 09 LEVEL THE WARDROBE SYSTEM. 27




Garden Party Garment Rack

DESIGNED IN 2021

ASSEMBLY NOTES | REV 03






NEED A HAND?

Contact us at **service@bludot.com** or **844.425.8368** for assistance.

@BLUDOT

We design all our pieces in our Minneapolis studio. Follow along on Instagram for some sneak peeks into the process.




4 | 844.425.8368 GARDEN PARTY GARMENT RACK

ATTACH THE BASE TO THE GARMENT RACK UPRIGHTS.


Be sure to rest unit on a soft surface such as a rug or carpet.


Using the provided hardware, attach the garment rack uprights and adjustable glides to the base as shown.



ATTACH THE WOOD HOOKS.

Use the provided hardware to attach the wood hooks to the uprights as shown.








ATTACH THE TOP AND HANGING TUBE.

Please have two people perform this step.

- A) Slot both tubes into the fixed upright and attach one of the bolts.
- B) Then slot the tubes into the other upright simultaneously and install the second bolt.











ATTACH THE SHELF.

Attach the shelf as shown using the provided hardware.






8 | 844.425.8368

LEVEL THE GARMENT RACK.

If necessary, level the base by twisting the adjustable glides underneath.




Garden Party Shelving

DESIGNED IN 2021

ASSEMBLY NOTES | REV 03






NEED A HAND?

Contact us at **service@bludot.com** or **844.425.8368** for assistance.

@BLUDOT


We design all our pieces in our Minneapolis studio. Follow along on Instagram for some sneak peeks into the process.



ATTACH NARROW BASE TO SHELF UPRIGHTS.

Be sure to rest unit on a soft surface such as a rug or carpet.

Using the provided hardware, attach the shelf uprights to the narrow base as shown.





12 | 844.425.8368 GARDEN PARTY SHELVING


ATTACH THE UPPER BAR AND SHELF.

A) Slide the upper bar into the top of each upright.

B) Attach the top shelf as shown using the provided hardware. **Note: Careful when** assembling the top shelf as pulling the uprights apart will dislodge the upper bar.








ATTACH THE REMAINING SHELVES.

Using the provided hardware, attach the three remaining shelves as shown.







14 | 844.425.8368 GARDEN PARTY SHELVING

ATTACH THE WOOD HOOKS.


Use the provided hardware to attach the wood hooks to the outer uprights as shown.





LEVEL THE BASE.

If necessary, level the bases by twisting the adjustable glides on the bottom of the base.




16 | 844.425.8368 GARDEN PARTY SHELVING

Garden Party Wardrobe System

DESIGNED IN 2021

ASSEMBLY NOTES | REV 03






NEED A HAND?

Contact us at **service@bludot.com** or **844.425.8368** for assistance.

@BLUDOT

We design all our pieces in our Minneapolis studio. Follow along on Instagram for some sneak peeks into the process.


Parts & Hardware



ATTACH NARROW BASE TO SHELF UPRIGHTS.

Be sure to rest unit on a soft surface such as a rug or carpet.


Using the provided hardware, attach the shelf uprights and adjustable glides to the narrow





ATTACH THE UPPER BAR AND SHELF.

A) Slide the upper bar into the top of each upright. Loosely attach the provided hardware as shown.

B) Attach the top shelf as shown using the provided hardware. **Note: Tighten** the hardware only after both pieces are attached.









ATTACH THE REMAINING SHELVES.

Using the provided hardware, attach the three remaining shelves as shown.







ATTACH THE WIDE BASE TO THE GARMENT RACK UPRIGHTS.

Be sure to rest unit on a soft surface such as a rug or carpet.

Using the provided hardware, attach the garment rack uprights and adjustable glides to the wide base as shown.









ATTACH THE WOOD HOOKS.

Use the provided hardware to attach the wood hooks to the outer uprights as shown.








ATTACH THE TOP AND HANGING TUBE.

Please have two people perform this step.

- A) Slot both tubes into the fixed upright and attach one of the bolts.
- B) Then slot the tubes into the other upright simultaneously and install the second bolt.











ATTACH THE WIDE SHELF.

Attach the wide shelf as shown using the provided hardware.





LEVEL THE WARDROBE SYSTEM.

If necessary, level the bases by twisting the adjustable glides in the bottom of the wardrobe system.



Additional Information CLEAN Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for wood and metal furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.

