



Cursive Desk

DESIGNED IN 2021

ASSEMBLY NOTES | REV 00




NEED A HAND?

Contact us at service@bludot.com or
844.425.8368 for assistance.

@BLUDOT


We design all our pieces in our Minneapolis studio. Follow
along on Instagram for some sneak peeks into the process.

Parts & Hardware



QTY 6

Pt. 5027




QTY 6

Pt. 5028




QTY 8

Pt. 1019



QTY 8

Pt. 3005



QTY 8

Pt. 3007



QTY 1

Pt. 9004



QTY 1

Pt. 9022




QTY 1

Leg #1: Back Right Leg




QTY 1

Leg #2: Center Back Leg




QTY 1

Leg #3: Front Leg



QTY 1

Leg #4: Left Leg Assembly



QTY 1


Desk




QTY 2

Hanging File Rod

How to use the cam lock system



Note direction of cam arrow.



Turn cam clockwise 1/2 turn or until tight.


Note direction of cam arrow.

Step 01

REMOVE THE DRAWERS.

This product is heavy. We recommend two people perform the assembly.


Place the desk upside down on a soft surface. Remove the drawers by opening them part way, then depress the trigger locks to disengage them from the drawer slides. Set them aside during assembly.



Step 02

ATTACH THE RIGHT LEGS.

Match each leg with its corresponding numbered location.
Attach the right legs as shown using the included hardware and following the cam lock steps on page 3.



*Side panel not shown for clarity.



PT. 5027 x 4



PT. 5028 X 4



PT. 1019 X 2




PT. 3005 X 2



PT. 3007 X 2



PT. 9004 X 1




PT. 9022 X 1

Step 03

ATTACH THE LEFT LEGS.

Attach the left legs as shown using the included hardware and following the cam lock steps on page 3.



PT. 5027 x 2



PT. 5028 X 2



PT. 1019 X 6



PT. 3005 X 6



PT. 3007 X 6



PT. 9004 X 1



PT. 9022 X 1

Step 04



RE-INSTALL DRAWERS.

We recommend two people perform this step.

Lift the desk upright. Re-install the drawers by setting them on the drawer slides and gently pushing them in until they click. The drawers should be secured by both the rear catches and trigger locks automatically. Confirm the drawers are properly secured by fully opening them.

Install the optional hanging file rods in the bottom drawer slots if desired.

If necessary, level the desk by twisting the adjustable glides on the bottom of each leg.



Additional Information

CLEAN

Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for wood furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.

