


# Verge Adjustable Sconce



DESIGNED IN 2021

ASSEMBLY NOTES | REV 00




NEED A HAND?

Contact us at [service@bludot.com](mailto:service@bludot.com) or  
**844.425.8368** for assistance.

@BLUDOT

We design all our pieces in our Minneapolis studio. Follow  
along on Instagram for some sneak peeks into the process.

# Parts & Hardware




QTY 2

PT. 1225




QTY 2

PT. 8052




QTY 1

Mounting Bracket



QTY 1

Wall Protector




QTY 1

Adjustable Sconce

# Step 01

## MARK MOUNTING LOCATIONS

Position the mounting bracket on the wall in your desired location. Ensure that the holes are vertical using a leveling device and mark the hole locations with a pencil.



# Step 02


## INSTALL MOUNTING BRACKET

Wall anchors and fasteners are included for installation into drywall. Please consult your local hardware professional to determine the hardware best suited for your wall type.

If the mounting locations are not positioned on a stud, drill **15/64"** holes in the marked locations and insert wall anchors.

If the mounting locations are positioned on a stud, this step of installing wall anchors may be skipped. Instead, drill **7/64"** pilot holes in the marked locations.

Position the mounting bracket in place with the mounting locations aligned. Install fasteners as shown.



PT. 8052 x 2\*




PT. 1225 x 2

# Step 03

## POSITION WALL PROTECTOR


Slide the wall protector over the installed mounting bracket as shown.



## Step 04

### ATTACH SCONCE.


Attach the sconce to the wall by carefully sliding it onto the mounting bracket.



# Step 05

REMOVE WALL PROTECTOR.

Remove the wall protector to complete installation.



## Additional Information

### USE

This unit is meant for indoor use in dry locations only.

### CLEAN

Unplug lamp prior to cleaning.

Clean powder-coated surfaces with a soft cloth or sponge using a mild detergent, such as dish soap, and warm water. Wipe completely dry with a soft cloth.

### REGULATORY

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

